

MANUAL TUBE PULLER

KSP



The KSP has been designed to make tube removal easy and economical when carrying out small quantity or hard to reach tube pulls.

- ▶ Simply insert the spear into the tube and thread it in with a handwrench until it has enough grip to extract the tube.
- ▶ Use another hand wrench on the black hex at the rear and this will press the front collar up against the tube sheet and allow the spear to pull the tube out.
- ▶ No external power is required.
- ▶ Durable - All parts made out of high strength steel and are heat treated.

TUBE OD	TUBE GAUGE	WALL THKS.		TUBE I.D.		TUBE PULLER NO.	SPARE SPEAR NO.
	[BWG]	[inch]	[mm]	[inch]	[mm]		
1/2"	14	0,08	2,11	0,334	8,48	KSP 500-14	KSP 1/2-14
	16	0,07	1,65	0,370	9,40	KSP500-16	KSP 1/2-16
	18	0,05	1,24	0,402	10,21	KSP 500-18	KSP 1/2-18
	20	0,04	0,89	0,430	10,92	KSP 500-20	KSP 1/2-20
5/8"	14	0,08	2,11	0,459	11,66	KSP 625-14	KSP 5/8-14
	16	0,07	1,65	0,495	12,57	KSP 625-16	KSP 5/8-16
	18	0,05	1,24	0,527	13,39	KSP 625-18	KSP 5/8-18
	20	0,04	0,89	0,555	14,10	KSP 625-20	KSP 5/8-20
3/4"	14	0,08	2,11	0,585	14,86	KSP 750-14	KSP 3/4-14
	16	0,07	1,65	0,620	15,75	KSP 750-16	KSP 3/4-16
	18	0,05	1,24	0,652	16,56	KSP 750-18	KSP 3/4-18
	20	0,04	0,89	0,680	17,27	KSP 750-20	KSP 3/4-20
7/8"	14	0,08	2,11	0,709	18,01	KSP 875-14	KSP 7/8-14
	16	0,07	1,65	0,745	18,92	KSP 875-16	KSP 7/8-16
	18	0,05	1,24	0,777	19,74	KSP 875-18	KSP 7/8-18
	20	0,04	0,89	0,805	20,45	KSP 875-20	KSP 7/8-20
1"	14	0,08	2,11	0,834	21,18	KSP 1000-14	KSP 1-14
	16	0,07	1,65	0,870	22,10	KSP 1000-16	KSP 1-16
	18	0,05	1,24	0,902	22,91	KSP 1000-18	KSP 1-18
	20	0,04	0,89	0,930	23,62	KSP 1000-20	KSP 1-20